

By Ed Bryan











Rich Sabreen

Modern	Masters	Metal	Effects				
	<u>1: Prime 1</u>	<u>2: Prime 2</u>	3: Oxidizing Paint 1	4: Oxidizing Paint 2	5: Green (or Blue) Patina Aging Solution	6: Rust Activator 1	7: Rust Activator 2
<u>Bronze</u>	Apply & wait 1/2 hour before next step	Apply & let dry for 12 hours before step 2	Apply & let dry	Apply & go to Step 3 while 2nd coat is wet	Spritz or natural sponge while 2nd oxidizing coat is wet	X	X
<u>Copper</u>	Apply & wait 1/2 hour before next step	Apply & let dry for 12 hours before step 2	Apply & let dry	Apply & go to Step 3 while 2nd coat is wet	Spitz or natural sponge while 2nd oxidizing coat is wet	X	X
<u>Iron</u>	Apply & wait 1/2 hour before next step	Apply & let dry for 12 hours before step 2	Apply & let dry	Let dry	X		Spritz 2nd Rust Activator coat 5 minutes after first Activator coat

Sources of Metallic Paint

Craft Supplies:

Modern Masters Metal Effects

https://woodturnerscatalog.com/search?q=metal+master&options%5Bprefix%5D=last

Klingspor:

Chromacraft Rustina Metal Aging Solutions

https://www.woodworkingshop.com/product/PARRUSTINA/